

# **ALEXIS** ASSEMBLY GUIDE





#### Important - Please read these instructions fully before starting assembly



CARE ADVICE



### SAFETY AND CARE ADVICE

- Check you have all the components and tools listed.
- Remove all fttings from the plastic bags and separate them into their groups.
- We do not recommend the use of power drills/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers and Allen keys.
- Keep children and animals away from the work area, small parts could cause choking if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Assemble the item as close to its final position (in the same room) as possible.
- Do not overtighten the nuts to avoid causing damage to the threads.

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit
- This product should not be discarded with household waste. Take to your local authority waste disposal centre




Follow us on Instagram @furniturebox\_uk

#### **IMPORTANT INFORMATION**



# PLEASE CHECK CAREFULLY AND MAKE SURE YOU HAVE ALL FITTINGS AND TOOLS LISTED BELOW BEFORE YOU START.



#### **NOTE:** The quantities above are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

www.furniturebox.co.uk




### STEP

Use a clear, flat, soft surface to avoid bumps or scratches.

Attach 1x top panel [1] to side panel [2] : Use 1x rod [A] and 1 x dowel [B] at either end of side panel, as per diagram.

Attach 1 x support panel [4] top top panel, using 2 x cam bolts [C2] and lock into place using 2 x cam locks [C1].


Repeat above process with other top, side and support panel, so you have two halves.



## STEP 2

Attach bottom panel [3]: Add 4x dowel rods [A} to side panels as per diagram.

Add 4x cam bolts and locks [C1 and C2} to support panels as per diagram. Align bottom panel 3 and gently tap into place. Lock support panels into place by twisting cam locks [C1} to tighten. Secure bottom panel by adding 1x washer [D] and 1x nut [E] to each corner, and tightening with spanner [F] BE CAREFUL NOT TO OVER TIGHTEN AND SPLIT THE WOOD.




Follow us on Instagram @furniturebox\_uk

#### FULL ASSEMBLY INSTRUCTIONS


### STEP 3


Add table feet: Add 1 x table foot [G] to each corner of bottom panel using 4x screws [H]



### STEP 4


Flip coffee table over. Add plastic pad [I] to inner runner edge of top panel.





www.furniturebox.co.uk





STEP 6

Your coffee table is now complete.



Follow us on Instagram @furniturebox\_uk

# LOOKING GOOD!

Now you've assembled your product find out how to care for your item and keep it looking brand new.



Look for your care guide in the box or visit: www.furniturebox.co.uk/club/care-guide

www.furniturebox.co.uk



### **OUR 1 YEAR GUARANTEE**

our products come with a 1 year guarantee to give you peace of mind shopping at Furniturebox



## WHAT THE GUARANTEE COVERS



**PRE-INSERTED FIXINGS** e.g. lose metal threads



e.g. metal discs removing from table top



**FAULTY JOINTS** e.g. legs bending



e.g. the frame of the product



### **ACTIVATE YOUR GUARANTEE ONLINE**

scan this QR code with your phone to read the full guarantee online and register your product. It only takes a moment to fill out. Or visit: furniturebox.co.uk/our-guarantee

Furniturebox UK, Beaumont Business Centre, Woodlands Road, Mere, Wiltshire, BA12 6BT Tel: 01747 863333 Email: sales@furniturebox.co.uk