


# ATHENS DINING TABLE

**ASSEMBLY GUIDE** 





#### www.furniturebox.co.uk

Scan QR code for more tips, advice and assembly video or visit furniturebox.co.uk/club/athens-dining



#### Important - Please read these instructions fully before starting assembly





#### SAFETY AND CARE ADVICE

- Check you have all the components and tools listed.
- Remove all fittings from the plastic bags and separate them into their groups.
- We do not recommend the use of power drills/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers and Allen keys.
- Keep children and animals away from the work area, small parts could cause choking if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Assemble the item as close to its final position (in the same room) as possible.
- Do not overtighten the nuts to avoid causing damage to the threads.

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners
- From time to time check that there are no loose screws on this unit
- This product should not be discarded with household waste. Take to your local authority waste disposal centre


#### IMPORTANT INFORMATION







### PLEASE CHECK CAREFULLY AND MAKE SURE YOU HAVE ALL FITTINGS AND TOOLS LISTED BELOW BEFORE YOU START.



**NOTE:** The quantities above are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



#### STEP 1

Use a clear, flat, soft surface to avoid bumps or scratches.

First, take base plate [3] and add 6x wooden dowels [D].




# (4) (B) A C E

#### STEP 2

Next, connect the central leg [4] to the base plate [3] using 2x washer [B] followed by screw [A]. Tighten with Allen key [C] then cover holes with 2x pads [E].

#### STEP 3


Connect both the outer legs [5] to the base plate. Use 2x washer [B] followed by screw [A]. Tighten with Allen key [C] then cover holes with 2x pads [E].



#### **FULL ASSEMBLY INSTRUCTIONS**

#### STEP 4

Attach connecting plate [2] to the tops of the table legs. Use 4 x washers [B] followed by screws [A] per leg - 12 washers and screws total. Tighten with Allen key [C].




## 

#### STEP 5

Carefully place table top [1] on top of connecting plate [2]. Line up the holes and secure the connecting plate to the table top using 6 x washer [B] then screw [A] - 3 sets on each side. Tighten with Allen key [C] and cover holes with 6 x pads [E].









# WE **LVVE** INTERIORS! SHARE YOURS WITH US ON SOCIAL MEDIA

- follow us on Instagram
   post your interior
- 3. tag us to be featured



@furnitureboxUK



@furniturebox\_uk



@furnitureboxuk

# **LOOKING GOOD!**

Now you've assembled your product find out how to care for your item and keep it looking brand new.




Look for your care guide in the box or visit: www.furniturebox.co.uk/club/care-guide



#### **OUR 1 YEAR GUARANTEE**

our products come with a 1 year guarantee to give you peace of mind shopping at Furniturebox



#### WHAT THE GUARANTEE COVERS



**PRE-INSERTED FIXINGS** e.g. lose metal threads



**FAULTY JOINTS** e.g. legs bending



e.g. metal discs removing from table top



e.g. the frame of the product



#### **ACTIVATE YOUR GUARANTEE ONLINE**

scan this QR code with your phone to read the full guarantee online and register your product. It only takes a moment to fill out. Or visit: furniturebox.co.uk/our-guarantee

Furniturebox UK, Beaumont Business Centre, Woodlands Road, Mere, Wiltshire, BA12 6BT Tel: 01747 863333 Email: sales@furniturebox.co.uk