

CALLA

ASSEMBLY GUIDE



www.furniturebox.co.uk

Scan QR code for more tips, advice and assembly video or visit furniturebox.co.uk/club/calla



Important - Please read these instructions fully before starting assembly





SAFETY AND CARE ADVICE

- Check you have all the components and tools listed.
- Remove all fittings from the plastic bags and separate them into their groups.
- We do not recommend the use of power drills/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers and Allen keys.
- Keep children and animals away from the work area, small parts could cause choking if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Assemble the item as close to its final position (in the same room) as possible.
- Do not overtighten the nuts to avoid causing damage to the threads.

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit
- This product should not be discarded with household waste. Take to your local authority waste disposal centre


IMPORTANT INFORMATION








PLEASE CHECK CAREFULLY AND MAKE SURE YOU HAVE ALL FITTINGS AND TOOLS LISTED BELOW BEFORE YOU START.








Rear Legs = Angled Front Legs = Straight

IMPORTANT: 1 package contains x2 front legs and the other package contains x2 rear legs. One leg from each box makes up x1 chair. The legs at the front of the chairs are straight and the rear legs are angled outwards.

NOTE: The quantities above are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



STEP 1




Please use one leg from each pack in the box.



STEP 2

Place the back and seat cushion part [A] upside down over the edge of a stable table to work on.

Attach the legs to the chair base. Align the tabs in the leg frame with the holes in the chair base. Secure using washer [A] followed by spring washer [B] then bolt [B]. Tighten with Allen key [G].





STEP 3

Carefully flip the chair onto its legs. Check for stability. Your chair is now ready to use.





WE LYVE INTERIORS! SHARE YOURS WITH US ON SOCIAL MEDIA

- 1. follow us on Instagram
 - 2. post your interior
- 3. tag us to be featured



@furnitureboxUK



@furniturebox_uk



@furnitureboxuk

LOOKING GOOD!

Now you've assembled your product find out how to care for your item and keep it looking brand new.



Look for your care guide in the box or visit: www.furniturebox.co.uk/club/care-guide



OUR 1 YEAR GUARANTEE

our products come with a 1 year guarantee to give you peace of mind shopping at Furniturebox



WHAT THE GUARANTEE COVERS



PRE-INSERTED FIXINGS e.g. lose metal threads



FAULTY JOINTS e.g. legs bending



e.g. metal discs removing from table top



e.g. the frame of the product



ACTIVATE YOUR GUARANTEE ONLINE

scan this QR code with your phone to read the full guarantee online and register your product. It only takes a moment to fill out. Or visit: furniturebox.co.uk/our-guarantee

Furniturebox UK, Beaumont Business Centre, Woodlands Road, Mere, Wiltshire, BA12 6BT Tel: 01747 863333 Email: sales@furniturebox.co.uk