


# **EGG CHAIR**

# **ASSEMBLY GUIDE**





# www.furniturebox.co.uk

Scan QR code for more tips, advice and assembly video or visit furniturebox.co.uk/club/egg-chair



#### Important - Please read these instructions fully before starting assembly





#### SAFETY AND CARE ADVICE

- Check you have all the components and tools listed.
- Remove all fittings from the plastic bags and separate them into their groups.
- We do not recommend the use of power drills/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers and Allen keys.
- Keep children and animals away from the work area, small parts could cause choking if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Assemble the item as close to its final position (in the same room) as possible.
- Do not overtighten the nuts to avoid causing damage to the threads.

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners
- From time to time check that there are no loose screws on this unit
- This product should not be discarded with household waste. Take to your local authority waste disposal centre


#### IMPORTANT INFORMATION







# PLEASE CHECK CAREFULLY AND MAKE SURE YOU HAVE ALL FITTINGS AND TOOLS LISTED BELOW BEFORE YOU START.



NOTE: The quantities above are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.




Construct your furniture on a nice flat, soft surface like a carpet, rug, or the lawn, to avoid any bumps and scratches. First, lay out all your pieces and check you have all the items listed on the inventory.

#### STEP 1

Don't fully tighten any of the bolts until all of the components are in place.

Connect the side pieces [A] and [B] to the centre piece [C] using 6x bolts [H] and 12x washers [J] with 6x nuts [K]. Double check you're using the correct bolts here. Thread the bolts from the centre panel facing outwards, and secure with the washer and nuts from the side-panel side of the holes, as illustrated in the zoomed-in segment.




# 1 x12

# STEP 2

Connect the bottom piece [E] using 6x bolts [I] and 6x washers [J] with 6x nuts [L] and 6x washers [J]. Thread the bolts through the bottom piece, facing outwards, and secure with washers and nuts on the other side of the holes, as illustrated in the zoomed-in segment.

#### **FULL ASSEMBLY INSTRUCTIONS**




# STEP 3

Attach the top piece [D] using 3x bolts [I] and 3x washers [J] with 3x nuts [K]. Check you're using the correct bolts here. Thread the bolts through from the top piece facing in towards the side/back pieces, and secure with washers and nuts on the other side of the holes, as illustrated in the zoomed-in segment.


#### STEP 4

Carefully lay your seat facedown on the flat surface to attach the legs piece [F]. Use 4x bolts [G] and washers [J]. Thread bolts through from outside of piece [F] towards the inside of the seat.

Once everything is in place, go ahead and tighten all of the bolts, but take care not to over-tighten.







# STEP 5

Carefully, and with help, stand your egg chair on its feet and check stability. Add cushions [N, O and 2x P]. Your egg chair is now complete!





# WE LYVE INTERIORS! SHARE YOURS WITH US ON SOCIAL MEDIA

- 1. follow us on Instagram
  - 2. post your interior
- 3. tag us to be featured



@furnitureboxUK



@furniturebox\_uk



@furnitureboxuk



www.furniturebox.co.uk



#### **OUR 1 YEAR GUARANTEE**

our products come with a 1 year guarantee to give you peace of mind shopping at Furniturebox



#### WHAT THE GUARANTEE COVERS



**PRE-INSERTED FIXINGS** e.g. lose metal threads



**FAULTY JOINTS** e.g. legs bending



e.g. metal discs removing from table top



e.g. the frame of the product



#### **ACTIVATE YOUR GUARANTEE ONLINE**

scan this QR code with your phone to read the full guarantee online and register your product. It only takes a moment to fill out. Or visit: furniturebox.co.uk/our-guarantee

Furniturebox UK, Beaumont Business Centre, Woodlands Road, Mere, Wiltshire, BA12 6BT Tel: 01747 863333 Email: sales@furniturebox.co.uk