



MONACO 10

ASSEMBLY GUIDE



www.furniturebox.co.uk

Scan QR code for more tips, advice
and assembly video or visit
furniturebox.co.uk/club/monaco-10

Important - Please read these instructions fully before starting assembly



**SAFETY AND
CARE ADVICE**



NO POWER TOOLS

SAFETY AND CARE ADVICE

- Check you have all the components and tools listed.
- Remove all fittings from the plastic bags and separate them into their groups.
- We do not recommend the use of power drills/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers and Allen keys.
- Keep children and animals away from the work area, small parts could cause choking if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Assemble the item as close to its final position (in the same room) as possible.
- Do not overtighten the nuts to avoid causing damage to the threads.
- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit
- This product should not be discarded with household waste. Take to your local authority waste disposal centre



Follow us on Instagram
@furniturebox_uk

IMPORTANT INFORMATION



**45 MINUTE
BUILD**



**TWO
PERSON**



**MAXIMUM
CAPACITY 100Kg**

**PLEASE CHECK CAREFULLY AND MAKE SURE YOU HAVE ALL
FITTINGS AND TOOLS LISTED BELOW BEFORE YOU START.**

A 2pcs		B 1pc		C 2pcs	
D 2pcs		E 1ps		F1 2pcs	
F 6pcs		G 6pcs		H 6pcs	
I 6pcs		J 6pcs		K 6pcs	
M 4pcs		N 8 pcs		O 8 pcs	
P 4pcs		Q 12pcs		R 12pcs	
S 12pcs		T 1pc		U 1pc	
V 54pcs		W 48pcs		F2 1pc	

NOTE: The quantities above are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

Construct your furniture on a nice flat, soft surface like a carpet, rug, or the lawn, to avoid any bumps and scratches. First, lay out all your pieces and check you have all the items listed on the inventory.

TABLE: STEP 1

Place the central tabletop piece [B] face-down on the flat surface and attach 2x tabletop end pieces [A] to either side. Use 1x bolt + washer set [Q] on one side of the hole and secure with washer + nut set [S] on the other side of the hole. Repeat as illustrated across the 4 holes.

Don't fully tighten any of the bolts until everything is in place.





TABLE: STEP 2

Attach 2 x long leg frames [C] to the central tabletop [B], using 2x bolt + washer sets [R] at each end of the leg frames - 8 in total. Double check you're using the correct bolts here.




TABLE: STEP 3

Connect 2 x short leg frames [D]; 1 at either end of the tabletop. Use 2x bolt + washer sets [R] on each leg frame. Connect middle frame [E] to long leg frame [C].

Use 1x bolt + washer set [Q] on one side of the hole and secure with washer + nut set [S] on the other side of the hole. Repeat as illustrated across the 4 holes.



Follow us on Instagram
@furniturebox_uk




furniturebox

CHAIR: STEP 1

Take the chair seat back frame [H] and attach it to right side frame [F], using washer and bolt sets [V]. Attach the chair base frame [I], using 3x washer and bolt sets [V].


Don't fully tighten any of the bolts until everything is in position.



CHAIR: STEP 2

Attach the seat back support [J] to right side frame [F], attach left side frame [G], using 3x washer and bolt sets [V].


Once everything is in position, tighten the bolts with the Allen key provided (but take care not to over-tighten). Check the stability.



CHAIR: STEP 3

Fix the seat back support [J], using 2x washer and bolt sets [V]. Add seat cushion [K], and your chair is complete!

Repeat for the other 5 chairs.







furniturebox

Construct your furniture on a nice flat, soft surface like a carpet, rug, or the lawn, to avoid any bumps and scratches. First, lay out all your pieces and check you have all the items listed on the inventory.

STOOL: STEP 1

Take the seat base [M] and place it face-down on your flat surface. Take 2x side panels [O] and 2 x side panels [N]. Connect them together and to the seat base [M] using the washer and bolt sets [W] - double check you're using the correct bolts. You need 12 sets of washers and bolts [W] in total for one stool.

Don't fully tighten all the bolts until all the parts are in place. Once everything is connected, tighten with the Allen key provided, but take care not to over-tighten.



STOOL: STEP 2

Carefully flip the stool onto its feet and add the padded seat cushion [P]. Your stool is now complete!

Repeat for the other 3 stools.



Follow us on Instagram
@furniturebox_uk

LOOKING GOOD!

Now you've assembled your garden furniture find out how to care for your item and keep it looking brand new.



Look for your care guide in the box or visit:
www.furniturebox.co.uk/club/care-guide

www.furniturebox.co.uk



OUR 1 YEAR GUARANTEE

our products come with a 1 year guarantee
to give you peace of mind shopping at
Furniturebox



WHAT THE GUARANTEE COVERS



PRE-INSERTED FIXINGS
e.g. lose metal threads



FAULTY JOINTS
e.g. legs bending



EXTERNAL FIXING FAULTS
e.g. metal discs removing
from table top



STRUCTURAL INTEGRITY
e.g. the frame of the
product



ACTIVATE YOUR GUARANTEE ONLINE

scan this QR code with your phone to read
the full guarantee online and register your
product. It only takes a moment to fill out.
Or visit: furniturebox.co.uk/our-guarantee

Furniturebox UK, Unit 6, St Modwen's Park,
Chippenham, SN15 5BD
Tel: 01747 863333 Email: sales@furniturebox.co.uk