

NORA CHAIR ASSEMBLY GUIDE





Important - Please read these instructions fully before starting assembly





SAFETY AND CARE ADVICE

- Check you have all the components and tools listed.
- Remove all fittings from the plastic bags and separate them into their groups.
- We do not recommend the use of power drills/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers and Allen keys.
- Keep children and animals away from the work area, small parts could cause choking if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Assemble the item as close to its final position (in the same room) as possible.
- Do not overtighten the nuts to avoid causing damage to the threads.


- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit
 - This product should not be discarded with household waste. Take to your local authority waste disposal centre



IMPORTANT INFORMATION



PLEASE CHECK CAREFULLY AND MAKE SURE YOU HAVE ALL FITTINGS AND TOOLS LISTED BELOW BEFORE YOU START.




NOTE: The quantities above are the correct amount to complete the assembly for 2x chairs. In some cases more fittings may be supplied than are required.



Place seat upside down onto a clean, flat surface.

Carefully align the leg frame onto the seat and secure with 1x washer [A] + 1x spring washer [B] + 1x bolt [C] in each hole. Tighten with Allen key [D].





Follow us on Instagram @furniturebox_uk



STEP 2 Turn the chair the right way up to complete assembly.





Follow us on Instagram @furniturebox_uk





WE **LVVE** INTERIORS! SHARE YOURS WITH US ON SOCIAL MEDIA

follow us on Instagram
post your interior
tag us to be featured







www.furniturebox.co.uk

LOOKING GOOD!

Now you've assembled your product find out how to care for your item and keep it looking brand new.



www.furniturebox.co.uk/club/care-guide



OUR 2 YEAR* GUARANTEE

our products come with a 2 year guarantee to give you peace of mind shopping at Furniturebox

*excludes some garden furniture items which have a 1 year guarantee



WHAT THE GUARANTEE COVERS



e.g. lose metal threads





FAULTY JOINTS e.g. legs bending



e.g. bonding/glue

e.g. the frame of the product

ACTIVATE YOUR GUARANTEE ONLINE

scan this QR code with your phone to read the full guarantee online and register your product. It only takes a moment to fill out. Or visit: furniturebox.co.uk/our-guarantee

Furniturebox UK, Unit 6, St Modwen's Park, Chippenham, SN15 5BD Tel: 01747 863333 Email: sales@furniturebox.co.uk