


SAMBA

ASSEMBLY GUIDE





www.furniturebox.co.uk

Scan QR code for more tips, advice and assembly video or visit furniturebox.co.uk/club/samba-tv



Important - Please read these instructions fully before starting assembly





SAFETY AND CARE ADVICE

- Check you have all the components and tools listed.
- Remove all fittings from the plastic bags and separate them into their groups.
- We do not recommend the use of power drills/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers and Allen keys.
- Keep children and animals away from the work area, small parts could cause choking if swallowed
- Make sure you have enough space to layout the parts before starting.
- Assemble the item as close to its final position (in the same room) as possible.
- Do not overtighten the nuts to avoid causing damage to the threads.

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners
- From time to time check that there are no loose screws on this unit
- This product should not be discarded with household waste. Take to your local authority waste disposal centre

IMPORTANT INFORMATION











PERSON


30 MINUTE BUILD

MAXIMUM CAPACITY 80Kg

GLASS

IMPORTANT STEP

PLEASE CHECK CAREFULLY AND MAKE SURE YOU HAVE ALL FITTINGS AND TOOLS LISTED BELOW BEFORE YOU START.



NOTE: The quantities above are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



STEP 1

Use a clear, flat, soft surface to avoid bumps or scratches.


Take top panel [1]. Screw in 6 x dowel rods [A] and 6x rods [B] into holes as shown.


Next, make up all 6 of your drawer runners. there are 3 drawers, each with a left and right side boards. Each side board has a runner.


Make sure you identify which are left side boards [2], [4] and [6] and which are right side boards [3], [5] and [7].

Screw runner [F] on to each side board using 2x screw [G].

ATTENTION: Be careful not to over-screw beyond the thread stops.







STEP 2


Slot 1 x little back board [14] into the grooves of side boards [2] and [3] to make 1 drawer support. Make sure you're using the correct back board - back board [14] is the widest of the 3 back board pieces (this is the deepest drawer). Thread this onto the rods you attached to the top panel in Step 1, as per diagram.

Attach the side stand panel [9] to the top panel by threading it onto the rods you attached to the top panel in Step 1, as per diagram.

Next, carefully lower 1 x tempered glass shelf sheet [18] onto the rods.


STEP 3

Repeat Step 2 to make the next drawer support, using the little back board [15] and side boards [4] and [5]. Thread this onto the rods and then lower on 1 x tempered glass shelf sheet [18]










STEP 4

Construct the final drawer.
Connect side boards [6] and [7] to bottom board [8] using 4x cam bolts and locks [I1] and [I2]. **Don't over-tighten the cam bolts [I2], you could split the wood**. Lock bottom board [8] into place by twisting the cam locks [I1]. Then slot little back board [16] into the grooves on the side and bottom boards.

Lower this last drawer onto the rods, as per diagram.






Connect 1 x left drawer side board [10] and 1 x right drawer side board [11] to 1 x drawer back board [12] using 4x screws [H] as per diagram. Slot drawer bottom board [13] into grooves on side and back boards.

Attach drawer front board [17] using 4x cam bolts and locks [11] and [12] as shown in diagram. Don't over-tighten the cam bolts [12]. Twist cam locks [11] into place by twisting.

Finally, attach 1x thin drawer runner [F] to either side of the drawer using 2x screw [G] per runner.




STEP 7

Repeat Step 6 for your other 2 drawers.


Carefully, and with help, flip your unit over so it's now correct side-up. Drawer supports will be on the left.

Attach the 4 x glass shelf supports [J] using screw [K]. 2 supports per shelf, front and back, as per diagram.



STEP 8 ATTENTION: Carefully slot your drawers into the supports.


Your TV stand is now ready to use.





OUR 1 YEAR GUARANTEE

our products come with a 1 year guarantee to give you peace of mind shopping at Furniturebox



WHAT THE GUARANTEE COVERS



PRE-INSERTED FIXINGS e.g. lose metal threads



FAULTY JOINTS e.g. legs bending



e.g. metal discs removing from table top



e.g. the frame of the product



ACTIVATE YOUR GUARANTEE ONLINE

scan this QR code with your phone to read the full guarantee online and register your product. It only takes a moment to fill out. Or visit: furniturebox.co.uk/our-guarantee

Furniturebox UK, Beaumont Business Centre, Woodlands Road, Mere, Wiltshire, BA12 6BT Tel: 01747 863333 Email: sales@furniturebox.co.uk