

# SEATTLE DINING **TABLE ASSEMBLY GUIDE**



## www.furniturebox.co.uk

Scan QR code for more tips, advice and assembly video or visit furniturebox.co.uk/club/seattle



#### Important - Please read these instructions fully before starting assembly





### SAFETY AND CARE ADVICE

- Check you have all the components and tools listed.
- Remove all fittings from the plastic bags and separate them into their groups.
- We do not recommend the use of power drills/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers and Allen keys.
- Keep children and animals away from the work area, small parts could cause choking if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Assemble the item as close to its final position (in the same room) as possible.
- Do not overtighten the nuts to avoid causing damage to the threads.

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit
- This product should not be discarded with household waste. Take to your local authority waste disposal centre




Follow us on Instagram @furniturebox\_uk

#### **IMPORTANT INFORMATION**



# PLEASE CHECK CAREFULLY AND MAKE SURE YOU HAVE ALL FITTINGS AND TOOLS LISTED BELOW BEFORE YOU START.




**NOTE:** The quantities above are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

www.furniturebox.co.uk




Use a clear, flat, soft surface to avoid bumps or scratches.

Place the tabletop [1] face down and connect the 4x table legs [2]. Align all of the pre-drilled holes and connect using 3 x washers [B] followed by 3 x bolts [A] on each leg - 12 in total. Tighten with Allen key [C].



STEP 2

Carefully, and with help, flip your table onto its feet. Check for stability. Your table is now ready to use!





Follow us on Instagram @furniturebox\_uk

# LOOKING GOOD!

Now you've assembled your product find out how to care for your item and keep it looking brand new.



www.furniturebox.co.uk



## **OUR 2 YEAR\* GUARANTEE**

our products come with a 2 year guarantee to give you peace of mind shopping at Furniturebox

\*excludes some garden furniture items which have a 1 year guarantee



# WHAT THE GUARANTEE COVERS



**PRE-INSERTED FIXINGS** e.g. lose metal threads





FAULTY JOINTS e.g. legs bending



**EXTERNAL FIXING FAULTS** e.g. bonding/glue e.g. the frame of the product



## **ACTIVATE YOUR GUARANTEE ONLINE**

scan this QR code with your phone to read the full guarantee online and register your product. It only takes a moment to fill out. Or visit: furniturebox.co.uk/our-guarantee

Furniturebox UK, Unit 6, St Modwen's Park, Chippenham, SN15 5BD Tel: 01747 863333 Email: sales@furniturebox.co.uk