





SEYCHELLES

ASSEMBLY GUIDE



SCAN ME

www.furniturebox.co.uk

Scan QR code for more tips,
advice and assembly video or visit
furniturebox.co.uk/club/seychelles

Important - Please read these instructions fully before starting assembly



SAFETY AND CARE ADVICE



NO POWER TOOLS

SAFETY AND CARE ADVICE

- Check you have all the components and tools listed.
- Remove all fittings from the plastic bags and separate them into their groups.
- We do not recommend the use of power drills/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers and Allen keys.
- Keep children and animals away from the work area, small parts could cause choking if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Assemble the item as close to its final position (in the same room) as possible.
- Do not overtighten the nuts to avoid causing damage to the threads.
- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit
- This product should not be discarded with household waste. Take to your local authority waste disposal centre



Follow us on Instagram
@furniturebox_uk

IMPORTANT INFORMATION



45 MINUTE
BUILD



TWO
PERSON



MAXIMUM
CAPACITY
120Kg

PLEASE CHECK CAREFULLY AND MAKE SURE YOU HAVE ALL FITTINGS AND TOOLS LISTED BELOW BEFORE YOU START.

A		1PC	J		1PC
B		4PC	F		6 PC
C		16PC	C		24 PC
D		16PC	D		24 PC
E		1PC	E		1PC
H		1PC	G		3 PC
F		3PC	S		1PC
C		12PC	R		2 PC
D		12PC	G		8 PC
			C		24 PC
			D		24 PC

NOTE: The quantities above are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.




STEP 1

Use a clean, flat, soft surface to avoid any bumps or scratches.

Assemble the table.

Place tabletop frame [A] face down on the flat surface. Attach 4x legs [B] by aligning the pre-drilled holes and securing with 4x washers [D] followed by 4x bolts [C] on each leg - 16 in total. Tighten with Allen key [E].

Carefully, and with help, flip your table onto its feet. Check for stability.




Follow us on Instagram
@furniturebox_uk

STEP 2

Assemble the corner chair.

Flip the corner chair seat [H] over - use the edge of a table to help support if needed. Attach the 4x chair legs. Note - 3 legs are tapered [F] and 1 leg is straight [G] - leg [G] connects to the inner corner of the chair. Align the pre-drilled holes and connect using 3x washers [D] followed by 3x bolts [C] for each leg - 12 in total. Fully tighten all bolts with Allen key [E].

Turn the corner chair over to sit on its legs and check stability.



STEP 3



Assemble the sofa sections - there are 2 of these, for left and right sides of the corner chair. Assembly is the same for both.

Flip sofa base [J] over - use the edge of a table to help support if needed. Attach the 4x sofa legs. Note - 3 legs are tapered [F] and 1 leg is straight [G] - leg [G]

connects to the inner corner of the sofa. Align the pre-drilled holes and connect using 3x washers [D] followed by 3x bolts [C] for each leg - 12 in total. Fully tighten all bolts with Allen key [E].

Carefully and with help turn the sofa over so it rests on its legs. Check stability.

Repeat for the 2nd sofa.



STEP 4



Assemble the benches - there are 2 of these.

Flip bench top [R] over and attach 4x legs [G]. Align the pre-drilled holes and secure with using 3x washers [D] followed by 3x bolts [C] for each leg - 12 in total. Fully tighten all bolts with Allen key [E].

Carefully and with help turn the bench over so it rests on its legs. Check stability.

Repeat for the 2nd bench.

Arrange your sofas either side of the corner chair. Your sofa set is now ready to use.





OUR 1 YEAR GUARANTEE

our products come with a 1 year guarantee to give you peace of mind shopping at Furniturebox



WHAT THE GUARANTEE COVERS



PRE-INSERTED FIXINGS
e.g. lose metal threads



FAULTY JOINTS
e.g. legs bending



EXTERNAL FIXING FAULTS
e.g. metal discs removing
from table top



STRUCTURAL INTEGRITY
e.g. the frame of the
product



ACTIVATE YOUR GUARANTEE ONLINE

scan this QR code with your phone to read the full guarantee online and register your product. It only takes a moment to fill out. Or visit: furniturebox.co.uk/our-guarantee

Furniturebox UK, Unit 6, St Modwen's Park,
Chippenham, SN15 5BD
Tel: 01747 863333 Email: sales@furniturebox.co.uk